



TELEPÍTÉS

Extra erős ProClip



Please read the instructions and look at the pictures before attaching the bracket.

1. Use the enclosed alcohol pad to clean the area where the bracket is to be installed. Peel off the adhesive tape cover on the bracket. Press the angled edge on the lower part of the bracket into the seam/gap between the stereo/navigation screen and the surrounding panel frame.



2. Press firmly forward on the upper part of the bracket, flexing it forward. While flexing, hook the upper angled edge of the bracket around the compartment edge. Then press downward on the top of the bracket for best possible attachment of the adhesive tape.



3. The bracket is in place.

4. The bracket is in place.

Az alábbiakkal kompatibilis

- Jeep Wrangler (2011-2018)

