



TELEPÍTÉS

Extra erős ProClip



Please read the instructions and look at the pictures carefully before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the angled right edge of the ProClip into the gap on the right side of the vent frame.



2. Flex the left side of the ProClip to the right and insert the angled left edge into the gap on the left side of the vent frame.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Dodge Grand Caravan (2011-2020)

