



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Rest the mount between the screen and cup holder. Insert the two gap openers into the seam along the front dashboard trim so they are on each side of the mount. Press the edge of the mount into the gap between the gap openers. Pull out the gap openers.



2. Press the gap openers into the seam on the back side of the top dashboard trim. Press down on top of the mount until the edge clips into the seam between the gap openers. Press in on the edge to make sure it is fully seated. Pull out the gap openers.



3. Place the locking washer into the recess on top of the swivel plate. Place the faceplate on the swivel plate and angle as desired. Secure the faceplate to the mount using the included machine screw.

4. The ProClip mount is in place.

## Az alábbiakkal kompatibilis

- Chevrolet BrightDrop (2024-2026)