TELEPÍTÉS

Extra erős ProClip













Read through the entire installation instruction and study the pictures before installing the ProClip mount. Important: The mount must be installed before any holder or other accessory is attached. This mount consists of two parts: a mounting plate and a bracket.

1. Position the bracket behind the mounting plate and loosely attach the two parts using the enclosed screws.

2. Remove the rubber mat from the storage compartment. Locate the holes at the back of the compartment.

3. Hook the angled hooks of the bracket into the holes. Carefully tighten the screws until the mount is securely in place.

4. The ProClip mount is now installed. If needed, a pedestal mount can be attached to the plate.

Az alábbiakkal kompatibilis

- Scania P-series (2017-2024); Scania R-series (2017-2024); Scania S-series (2017-2024)