



TELEPÍTÉS

ModTek dokkoló



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the ModTek Dock so you can remove the tilt swivel attaching plate on the back.



2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.

3. Place the ModTek Dock over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the mount is firmly in place, but still can be adjusted.



4. The mount is in place.

Az alábbiakkal kompatibilis

