

TELEPÍTÉS

ModTek dokkoló



Please read all of the instructions and look at the pictures before attaching the holder.

1. Carefully connect the charging cable to the ModTek Dock.



2. Attach the tilt swivel to the ModTek Dock as shown in the image. Loosen the screw in the center of the ModTek Dock so you can remove the mounting plate from the back of the tilt swivel. Place the mounting plate in the desired position. Secure the mounting plate using the included screws.



3. Mount the ModTek Dock without the tilt swivel, place it in the desired position, and fasten it using the included screws.



4. The product is fully assembled.

Az alábbiakkal kompatibilis

