



# TELEPÍTÉS

## Szerelőlap



Please read all instructions and review the pictures before installing the mount. The photos show an example of how the mount can be installed on a Brodit Pedestal Mount.

1. Place the mount on the underside of the scanner and secure it using the included screws.



2. Position the mounting plate of the pedestal mount onto the mount, aligning the holes. Secure it using the included screws.

3. Install the pedestal mount in the desired location.

4. The product is in place.



## Az alábbiakkal kompatibilis

- Honeywell Vuquest 3320g

