

TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Press the right part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.



2. Press the right part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.

3. Press the left part of the ProClip into the gap between the dashboard and the frame surrounding the control panel.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Nissan Primera (2002-2009)

