



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of two of the enclosed gap openers into the gap between the panel surrounding the buttons and the dashboard, to widen the gap. Place then above the buttons, about 10 cm apart. Press the third gap opener into the gap below the buttons. Peel off the adhesive tape covers on the ProClip.



2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

3. Press the upper part of the ProClip into the gap between the gap openers. Pull out all gap openers.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Honda Odyssey (2005-2007)

