



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the thin ends of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Hook the angled edge on the lower part of the ProClip into the upper part of the air vent.



2. Press forward on the upper part of the ProClip so the angled edge on the upper part hooks into the gap between the gap openers.

3. Press downward on top of the upper part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap openers.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota HiAce (2007-2019)

