



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the rubber sealant and the A-post and flip open/pull out the rubber sealant slightly.



2. Press the angled edge on the lower part of the ProClip into the gap under the rubber sealant and hook it around the A-post.

3. Press the ProClip upward/rightward so the angled edge on the upper part hooks around the A-post by the windshield. Press until you hear/feel it snaps into place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Falcon FG-series (2008-2010)

