



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip into/around the air vent in the A-post panel.



2. Flip/push the upper part of the ProClip towards the windshield.

3. Press firmly upwards with your right hand on the bottom part of the ProClip and rightward on the left side of the ProClip with your other hand. When the angled edge on the upper part of the ProClip meets the windshield, press down on the left corner of the ProClip to get the angled edge goes into the gap between the windshield and the A-post panel. Then continue to press down over to the right corner of the ProClip.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Infiniti FX35 (2009-2012); Infiniti FX37 (2013-2015); Infiniti FX50 (2009-2013); Infiniti QX70 (2015-2020)

