



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press your fingers into the gap between the A-post panel frame and the rubber sealant, to widen the gap. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.



2. Press firmly upwards with your right thumb on the bottom part of the ProClip and rightward on the left side of the ProClip with your other fingers. Press until you see or hear/feel the angled edge on the upper part of the ProClip hook around the A-post panel edge.

3 The ProClip is in place.



4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Jeep Compass (2009-2016)

