



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the right part of the ProClip around the A-post.



2. Press the ProClip upward/forward so the angled edge on the left part of the ProClip hooks around the A-post by the windshield.

3. Press the upper part of the ProClip toward the A-post so the angled edge goes all the way into the gap.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Toyota LandCruiser 70 (2008-2017)

