



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly, to widen the gap.



2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

3. Press the ProClip upward/forward so the angled edge hooks over the A-post. Press downward on top of the ProClip so the edge goes all the way into the gap.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Mazda BT 50 (2013-2015)

