



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the air vent and the dashboard, to widen the gap. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Peel of the adhesive tape cover on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers until the edge goes all the way into the gap.



2. Pull out the gap openers. Press the gap openers into the gap between the panels surrounding the air vent and the dashboard.



3. Hook the angled edge on the upper part of the ProClip in the gap between the gap openers. Press the upper part of the ProClip downward so the angled edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Aurion (2013-2017)

