



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap.

2. Hook the angled edge of the ProClip around the A-post.



3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mercedes Benz Vito (2015-2023)

