



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Place the ProClip over the console edge. Press down on the ProClip so the thin edge on the right side of the ProClip goes into the gap between the center panel and the console edge.



2. Press down on the left side of the ProClip, towards the floor, so the angled edge snaps under the console edge.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Lexus LS Series (2001-2006)

