



TELEPÍTÉS

ProClip



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap in the console side wall. Pull the ProClip upwards so the lower edge hooks into the gap.



2. Pull the ProClip upwards and hook the angled edge of the upper part of the ProClip into the gap between the console and the panel surrounding the gear shift.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Holden Calais (2003-2006); Holden Commodore VY (2002-2007); Holden Executive (2003-2007)

