



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the right end of the ProClip over the edge of the console.
2. Press downwards on the left side of the ProClip so the angled edge on the right part hooks under the console.



3. The ProClip is in place.
4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mercedes Benz SLK-Class (2005-2010)

