

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled upper edge of the ProClip into the gap between the panel surrounding the gear shift and the console.



2. Pull the lower part of the ProClip downwards and hook under the edge of the console.

3. Press the ProClip towards the console so it hooks into place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jaguar S-Type (2002-2009)

