



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and the rubber boot, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the right side of the ProClip into the gap next to the gap opener. Pull out the gap opener.



2. Press firmly down on the left side of the ProClip so the angled edge hooks over the console edge by the floor. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Subaru Tribeca (2009-2008)

