

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.



2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.

3. Press downward on the left side of the ProClip so the angled edge on the lower part snaps into the gap in the console side wall. Pull out the gap opener.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Holden Calais (2007-2010); Holden Commodore Omega (2007-2010)

