

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the right side of the ProClip over the console edge.



2. Press down on the left side of the ProClip so the angled edge hooks around the console edge by the carpet.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Mazda MX-5 (2009-2015); Mazda Miata (2009-2015)

