



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the panel surrounding the gear shift and the edge of the console.



2. Press the right part into the gap.

3. Press downward on the left side of the ProClip so the angled lower edge hooks under the edge of the console.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Audi A6 (2011-2018); Audi A7 (2011-2017); Audi S6 (2011-2018)

