



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the floor console frame, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the right part of the ProClip into the gap next to the gap opener.



2. Press the left side of the ProClip downward so the curved right edge hooks under the panel surrounding the gear shift. Pull out the gap opener.



3. Press down on the left side of the ProClip so the angled edge hooks under the floor console frame. Press until you hear/feel it snap into place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Holden Commodore Berlina (2011-2013); Holden Commodore Calais (2011-2013); Holden Commodore Omega (2011-2013)

