



TELEPÍTÉS

ProClip



Please read all the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the right side of the ProClip over the console edge.



2. Press downward firmly on the left side of the ProClip so it flexes down towards the floor. Press until the angled edge on the lower part of the ProClip hooks around the console sidewall edge.

3. The ProClip is in place.



4 The ProClip is in place.

Az alábbiakkal kompatibilis

- Porsche 911 (Type 991) (2012-2019); Porsche Boxster (Type 981) (2012-2020); Porsche Cayman (Type 981) (2012-2021)

