



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the console sidewall and the panel, to widen the gap. Remove the adhesive tape covers on the ProClip. Press the angled edge of the ProClip into the gap above the gap opener. Remove the gap opener.



2. Press the ProClip forward, flexing it.

3. Hook the angled edge of the ProClip around the center console sidewall.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Holden Commodore VF (2014-2017)

