



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the angled edge on the right side of the ProClip over the console edge.



2. Press down on top of the ProClip so it flexes downward and the angled edge on the lower part of the ProClip hooks around the lower console edge. Push on the lower part of the ProClip to make sure the angled edge is hooked all way around.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Hyundai Tucson (2014-2015)

