



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the right side of the ProClip over the console edge.



2. Press down on the left side of the ProClip so the angled edge hooks under the console edge.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Volvo XC90 (2015-2024)

