



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap in the console sidewall.



2. Hook the upper right edge of the ProClip over the right edge of the top of the left console side panel.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jaguar F-PACE (2017-2020)

