



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: a faceplate and a mount.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Position the mount in-line with the front of the cup holders. Press the upper edge into the seam between the console top and console wall. Press down on the top of the mount until the lower edge clips under the top section of the console wall.



2. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or the passenger. Attach the faceplate to the mount with the included screw.



3. The ProClip mount is in place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Jeep Wagoneer S (2024-2026)