



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Press the upper part of the ProClip, with groove, into the gap between the air vent frame and the padded dashboard at pos.1. Press until you see or hear/feel it snap into place



2. Press the lower part of the ProClip into the gap between the padded part of the dashboard and the narrow wood grain panel at pos. 2. Press until you see or hear/feel it snap into place.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Volvo S80 (1999-2006)

