

TELEPÍTÉS

ProClip



Kérjük figyelmesen olvassa el a használati utasítást és nézze meg az ábrákat, mielőtt rögzíti a ProClip-et!

1. Press the curved edge on the right side of the ProClip into the gap between the panel frame and the padded dashboard.



2. Push forward on the left side of the ProClip towards the dashboard.

3. Press the grooved edge on the left side of the ProClip into the gap between the panel frame and the padded dashboard. Press until you see or feel it snaps into place.

4. The ProClip in place.



Az alábbiakkal kompatibilis

- Mazda 323 F (BJ) (1998-2002)
- Ford Laser (2000-2003)

