

TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip

Peel off both adhesive tape covers on the ProClip.

1. Press the right part of the ProClip into the gap between the frame surrounding the control panel and the frame surrounding the stereo.

2. Press forward on the ProClip so the angled edge of the left part of the ProClip hooks into the gap between the dashboard and the frame surrounding the control panel.

3. Press on the ProClip so it is properly in place.

4. The ProClip in place.



Az alábbiakkal kompatibilis

- Alfa Romeo Spider/GTV (1998-2005)

