



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: It is very important to place the ProClip in the exact same position as shown in the pictures.

1. Press the upper part of the ProClip into the gap between the dashboard and the panel surrounding the control panel. Press until you hear or see/feel it snap into place.



2. Press the lower part of the ProClip into the gap between the panel surrounding the air vents and the frame surrounding the control panel. Press until you hear or see/feel it snaps into place.

3. The ProClip is in place.



4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Jaguar X-Type (2001-2010)

