



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Hook the upper part of the ProClip, with groove, behind the upper edge of the air vent housing.



2. Press upward/forward on the lower part of the ProClip so it hooks behind the lower edge of the air vent housing.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Volkswagen Polo (2002-2009)

