



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.



2. Press the upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Land Rover Range Rover (2002-2006)

