



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the right part of the ProClip into the gap between the control panel and the surrounding frame.



2. Press forward on the ProClip, alternately on the left/right side, so the left edge hooks into the gap between the dashboard and the frame surrounding the control panel.

3. Press on the ProClip so it is properly in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jaguar S-Type (2002-2009)

