



TELEPÍTÉS

ProClip



Attention! Read all instructions and look at the pictures before attaching the ProClip. It is important to position the ProClip exactly as shown in the pictures.

1. Press the thin ends of the enclosed gap openers into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip.



2. Press the curved left edge of the ProClip into the gap between the control panel and the surrounding frame. Press rightwards on the ProClip so the left curved edge hooks into the gap.



3. Press forwards on the right side of the ProClip so the angled right edge hooks into the gap between the gap openers. Align upper edge of the right end of the ProClip with the gap in the dashboard. Pull the ProClip slightly upwards/downwards so you feel it is in place. Pull out the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Holden Calais (2003-2006); Holden Commodore VY (2002-2007); Holden Executive (2003-2007)

