



TELEPÍTÉS

ProClip



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the angled left part of the ProClip into the gap between the panel surrounding the air vent and the dashboard.



2. Press forwards on the right side of the ProClip.

3. Press the grooved edge of the right part of the ProClip into the gap between the dashboard and the frame surrounding the instrument panel

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Falcon (2003-2009)

