



TELEPÍTÉS

ProClip



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled right part of the ProClip into the gap between the frame surrounding the coin shelf and the surrounding control panel.



2. Press forwards on the ProClip so the long left part hooks behind the control panel.

3. Press on the ProClip so it is properly in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Echo (2003-2005); Toyota Yaris (2003-2005)

