



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the ProClip into the gap between the control panel and the surrounding frame.



2. Press forwards on the left side of the ProClip so the angled edge snaps into the gap between the frame surrounding the control panel and the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Subaru Legacy (2004-2006); Subaru Liberty (2003-2009); Subaru Outback (2003-2009)

