



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the rádió and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.



2. Press the angled edge on the left part of the ProClip into the gap in the dashboard.

3. Pull the ProClip upwards, towards the steering wheel, and hook the right end of the ProClip into the gap below the gap opener. Press forwards on the right end of the ProClip so it goes all the way into the gap. Pull out the gap opener.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford C-Max (2004-2010)

