



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Place the gap openers about 10 cm apart. Peel off the cover of the adhesive tape on the ProClip.



2. Press the grooved edge on the ProClip into the gap between the gap openers.

3. Press forwards on the ProClip until you hear/feel it snaps into place in the gap. Pull out the gap openers.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Territory (2004-2011)

