



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the grooved edge on the upper part of the ProClip against the air vent panel frame inside the air vent.



2. Press forward on the lower part of the ProClip so the grooved edge goes into the air vent and attaches to the lower air vent panel. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Volkswagen Golf V (2007-2009); Volkswagen Golf V Variant (2007-2009); Volkswagen Jetta (2006-2010)

