



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.



2. Flip the ProClip upwards so the curved lower edge hooks behind the stereo. Pull out the gap opener. Press the gap opener into the gap between the panel surrounding the air vent and the dashboard.



3. Press upwards/forwards on the ProClip so the angled upper edge hooks over the edge, into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Saab 9-5 (2006-2010)

