



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.



2. Press the curved edge on the right part of the ProClip into the above the gap opener. Start by pressing the upper corner into the gap, then follow through downwards so the edge goes into the gap. Flip the ProClip leftwards/forwards so the curved right edge hooks behind the control panel. Pull out the gap opener.



3. Press the left part of the ProClip towards the center console so the angled edge goes all the way into the gap and the adhesive tape attaches.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Saab 9-5 (2006-2010)

