



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Place the angled edge on the lower part of the ProClip in the lower edge of the air vent.



2. Press downwards/forwards on top of the ProClip so the grooved upper edge hooks into the upper part of the air vent.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Yaris (2006-2011)

