



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the upper part of the ProClip into the upper part of the air vent.



2. Hook the grooved edge on the lower part of the ProClip over the lower edge of the air vent.

3. Press on the ProClip so the adhesive tapes attach.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Toyota Tarago (2006-2016)

